




TSB090908-011

TECHNICAL SERVICE BULLETIN

SUBJECT: CONVEYOR BELT REINFORCING CLIPS

AFFECTED MODELS: SR, SRA AND AR SERIES HARVESTERS

The sprocket lugs on the rubber belts are reinforced with metal clips. Belt and sprocket damage will occur if any of the clips are excessively worn, damaged or missing. To prevent damage to the rubber belts and sprockets make sure that all of the clips are securely installed and in acceptable condition.



Periodically inspect the rubber belts on the rear conveyor. Worn clips are best seen looking at the underside of the belt. Replace any clips that are excessively worn, damaged or missing. **Call Bucyrus Equipment Company (800-330-0857) for replacement clips and installation tool.**

- Clips—part No. 04-149-01
- Installation tool—part No. TCI900